



User manual DIGIPASS 270

DIGIPASS – a Customer identification and document signature instrument for remote account management. It is an electronic device generating a unique test key for single use (a combination of digits replacing Customer identification by signature and seal).

Enable / Disable

DIGIPASS is turned on by pressing the "ON/OFF" button, located in the right lower corner of DIGIPASS keyboard and, holding it, press the "ENTER" button, which is located in the left lower corner of DIGIPASS keyboard. By pressing the "ON/OFF" button twice, the DIGIPASS device turns off. DIGIPASS turns off automatically if no button is pressed within 30 seconds.

Change of the PIN code

When the device is turned on for the first time, the initial PIN code has to be changed. To change the set PIN-code, turn on DIGIPASS and enter the bank issued PIN-code, then press and hold a few seconds the "ON/OFF" button until the "NEW PIN" appears on the device display. Enter the new 5-digit code, the PIN, and after the inscription "PIN CONF" re-enter it for the confirmation. After a successful replacement of the PIN-code on the display, DIGIPASS there will appear the inscription "NEW PIN CONF".

If it is necessary to change the PIN code chosen by You, the following steps have to be followed:

Your Activities	DIGIPASS display messages
Press buttons (ON/OFF) and	PIN
Enter PIN code (*****)	APPLI -
Press (ON/OFF) for 2 seconds	NEW PIN
Enter the PIN-code of 5 digits (One's own PIN-code of 5 digits)	PIN CONF
Re-enter the new PIN-code	NEW PIN CONF

Important! Entering easy to remember codes the message "not SAFE" will appear on the DIGIPASS device and it will request a new PIN code again.

Access code for entering the Internet bank

In order to connect to the Internet bank please use the Internet address <https://ib.ribbank.com>. Type your User code, provided by the Bank, and DIGIPASS code in the relevant fields of the page.

User's code	<input type="text" value="450000"/>	<input type="button" value="X"/>
Code of DigiPass device	<input type="text"/>	
<input type="button" value="Login"/>		

In order for the DIGIPASS device to generate the Access code, you need to do the following:

Your Activities	DIGIPASS display messages
Press buttons (ON/OFF) and	PIN
Enter PIN code (*****)	APPLI -
Press the Button 1	8-digit code

The 8 digits shown in the display is the Authorization code, which you need to enter in the appropriate window.

Authorisation code for sending orders

Any order sent to carry out an operation in the Internet bank is to be confirmed using the Authorisation code for sending orders, which will be requested on pressing the "Send" button in the Internet bank. Data input into the DIGIPASS device may be done only after the appearance of two 6-digit symbols on the monitor screen.

Digipass code generation data	Code 1: 057935 Code 2: 867010
Digipass Code *	<input type="text"/>

In order for the DIGIPASS device to generate this code, you need to do the following:

Your Activities	DIGIPASS display messages
Press buttons (ON/OFF) and	PIN
Enter PIN code (*****)	APPLI -
Press the Button 2	
Enter the code 1	1 -----
Enter the code 2	2 -----

A string of 8 digits on DIGIPASS screen after performing the above is the code of authorization of your order to the Bank, which must be entered in the appropriate box in the Internet bank. Pressing the button (ON / OFF) on the device, you can delete the incorrectly entered digits, or you can turn off the device to exit signature formation.

Entering the incorrect code and blocking DIGIPASS

If an incorrect PIN code is entered, a fault message appears on the display (FAIL 1 or FAIL 2). If the incorrect PIN code has been entered repeatedly and the DIGIPASS device turns off, on turning DIGIPASS on, the message FAIL 1 or FAIL 2 will appear. FAIL 1 denotes that the number of PIN code was entered incorrectly for the first time. FAIL 2 denotes that the PIN code has been entered incorrectly for the second time, and after the following mistake DIGIPASS will be blocked. If you have entered the PIN code incorrectly three times in succession, the message FAIL3 and lock pin will appear on the display, which means that DIGIPASS has been blocked. In this case you will have to contact the Bank to replace the DIGIPASS device.

Contacts

Customer Info Service: (+371) 67 359 000
J. Alunana Street 2, Riga, Latvia, LV-1010
bank@ribbank.com;
www.ribbank.com